

Quick Start Guide-90 Minute Runtime Model


Lighting Effects

Solid green light		Battery sufficiently charged
Solid red light		Battery low
Breathing red light		Charging


Tips for using

a – Installation


a. For the first use, distinguish the size of wheels according to their size, align the wheels with their positions, and simply press them in.




b. Insert 2 scrapers and 2 cover plates on the chassis assembly.



c. Install all functional components of the machine as shown in the following figure, ensuring that the upper shell is securely connected to the chassis.




d. Lock the outer casing assembly with 4 buckles.




b – Charging

Attention:
Please fully charge the device when first use







1) Quick charging time :around 3 hours.

2) Before use,fill the silicone plug into the charging port to prevent corrosion.



c – Applicability




1) Applicable area:within 80 m²

2) The machine is suitable for cleaning flat floors only.

Attention:
Not suitable for cleaning dirty swimming pools, but for daily cleaning and maintenance of your pool.



d – Putting



Do not throw the machine high into the water. The correct way is to put it slowly into the water by the pool.

1) Water sensor :Robot will examine for 60s ,it'll shut off after 60s without put into water.

e – Working



1) The robot's is random walking during working.


2) The battery is low , the robot will automatically stop along the wall.

Maintenance


Attention:

Long term operation of the machine may cause the impeller to become tangled with hair during rotation, resulting in malfunction. Please check the impeller every two months and cut off the tangled hair.

1) Remove the screws(see illustration) to detach the main unit from the upper cover.




2) Use needle-nose pliers to remove the small screw on the impeller to detach the impeller.



Note: Please keep the power off during operation.

3) Clean the hair tangled on the motor shaft and impeller.



4) After cleaning, reassemble the impeller and main unit in order.

FAQ

Q: Why won't the machine charge?

A: 1. Check if there is any debris blocking the charging port. If the charger isn't correctly connected, the device will not charge.
2. Before charging, dry the water inside the charging port.
3. Check if the LED indicator is on. If not, please contact customer service.

Q: Why is there water inside the product packaging?

A: 1. All machine undergo 100% water testing before shipping to ensure proper functionality. Therefore, it may find water droplets inside the packaging.

Q: Why is the indicator light is not on?

A: 1. Check if the machine is shut down, you can restart the machine by holding the red button for 3s.
2. May the machine is low battery, you need charging the machine.
3. If the LED indicator isn't on, please contact customer service.

Q: Why does the machine can't perform well when cleaning a dirty pool?

A: 1. If your swimming pool is too dirty and filled with too much sediment or sand, the filter can easily become clogged, and then the machine may stop working.
2. Not suitable for cleaning dirty swimming pools, but for daily cleaning and maintenance of your pool.

Q: Can the battery be replaced?

A: 1. Please Check the LED indicator to ensure the device is fully charged before cleaning.
2. Battery can't be replaced, The machine comes with 1-year warranty, including the battery and other parts.

Q: Why is the robot running slowly?

A: 1. Robots may find it difficult to climb slopes, so try to use them on flat pool bottoms.
2. When the swimming pool is very dirty, the robot's running resistance increases and runs slowly. Please clean the filter screen in a timely manner.

Q: Why has the machine stopped operating in water?

A First, ensure that the filter is properly installed. Next, check the impeller on the main unit for any hair or leaf entanglements; if present, please clear them. For detailed instructions, refer to the "Maintenance" section in the Quick Start Guide.

Support

poolease

For customer service and product warranty:

✉ poolease-service@outlook.com

www.poolease-clean.com